

Operation Manual

Wired Controller



IMPORTANT NOTE:

Thank you very much for purchasing our product. Before using your unit, please read this manual carefully and keep it for future reference.

Content

| | |
|--|----|
| 1.General | 1 |
| 1.1About the Manual | 1 |
| 1.2For User | 2 |
| 2. Wired Controller Installation | 2 |
| 2.1 Installation Dimensions | 2 |
| 2.2 Installation Steps | 3 |
| 3.Main Interface Overview | 4 |
| 3.1Using Homepages | 4 |
| 3.1.1Single Mode | 5 |
| 3.1.2Muti-Mode | 6 |
| 3.2Icon Description | 7 |
| 3.2.1Unit Status Icon | 7 |
| 3.2.2Water Temperature Icon | 8 |
| 4.Operation | 9 |
| 4.1ON/OFF Button | 9 |
| 4.2Mode Button | 9 |
| 4.3Function Button | 9 |
| 4.3.1User Function | 10 |
| 4.3.2Timer Function Setting | 11 |
| 4.3.3Wi-Fi Setting | 11 |
| 4.3.4DHW Return Water Function | 12 |
| 4.3.5Factory Function | 13 |
| 4.3.6Scene Setting | 13 |
| 4.3.7Dual Temperature Zone Control | 14 |
| 4.3.8SG Ready | 15 |
| 4.4Query Button | 16 |
| 4.4.1User Parameter | 16 |
| 4.4.2System Parameter | 16 |
| 4.4.3Notification | 17 |
| 4.4.4Power Statistics | 18 |
| 4.4.5Operation Curves | 19 |

| | |
|---|----|
| 4.4.6 Climate Temperature Curve..... | 19 |
| 4.5Setting Button | 20 |
| 4.5.1Date & Time..... | 21 |
| 4.5.2Dispaly & Sound | 22 |
| 4.5.3Factory Parameter | 22 |
| 4.5.4Restore Factory Setting | 23 |
| 4.5.5About | 24 |
| 5.Smart Life APP | 24 |
| 5.1Register & Login | 24 |
| 5.2Unit Binding..... | 25 |
| 5.3Using Homepage | 27 |
| 5.3.1ON/OFF..... | 27 |
| 5.3.2Mode Setting | 27 |
| 5.3.3Rename Unit..... | 28 |
| 5.3.4Remove Unit..... | 29 |
| 5.3.5Timer Setting | 30 |
| 5.3.6Operation Status Query | 30 |
| 6. Wired Controller Menu Structure Overview | 31 |
| 7.Appendix | 32 |
| 7.1Climate Temperature Curves | 32 |
| 7.1.1Heating Curves..... | 33 |
| 7.1.2Cooling Curves..... | 35 |
| 7.1.3DHW Curves..... | 37 |
| 7.2Error Code & Troubleshooting..... | 38 |
| 7.2.1 Motherboard | 38 |
| 7.2.2 Driver Board (Compressor)..... | 43 |
| 7.3Parameter | 44 |
| 7.3.1Operation Parameter | 44 |
| 7.3.2Factory Parameter | 45 |

1.General

1.1About the Manual

The original documentation is written in English. All other languages are translations. The precautions described in this document cover very important topics, follow them carefully. All activities described in the installation manual must be performed by an authorized installer.



WARNING:

Indicates a situation that could result in death or serious injury.



CAUTION:

Indicates a situation that could result in minor or moderate injury.



DANGER:

Indicates a situation that results in death or serious injury.



DANGER: RISK OF ELECTROCUTION:

Indicates a situation that could result in electrocution.



DANGER: RISK OF BURNING:

Indicates a situation that could result in burning because of extreme hot or cold temperatures.



NOTE:

Indicates a situation that could result in equipment or property damage.



INFORMATION:

Indicates useful tips or additional information.

1.2 For User

- If you are not sure how to operate the unit, contact your installer.
- The appliance is not intended for use by persons, including children, with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children must be supervised to ensure that they do not play with the product.



CAUTION:


DO NOT rinse the unit. This may cause electric shocks or fire.

- Unit are marked with the symbol:
- This means that electrical and electronic products cannot be mixed with unsorted household waste. **Do NOT** try to dismantle the system yourself: the dismantling of the system, treatment of the refrigerant, of oil and of other parts must be done by an authorized installer and must comply with applicable legislation. Units must be treated at a specialized treatment facility for reuse, recycling, and recovery. By ensuring this product is disposed of correctly, you will help to prevent potential negative consequences for the environment and human health. For more information, contact your installer or local authority.
- Placed in a location away from radiation.




2. Wired Controller Installation

2.1 Installation Dimensions



2.2 Installation Steps

① Remove the wired controller fixing plate, use screws to pass through the fixing plate, and use a screwdriver to fix it on the wall or junction box.




② Fasten the wired controller onto the fixing plate from top to bottom.



3.Main Interface Overview

3.1Using Homepages

After connecting the power , the controller will enter the language selection interface, after selecting the language, click "NEXT" to enter the welcome page;



NOTE:

If you don't operate it after entering the language selection interface, the first language will be selected by default after 2 minutes to enter the welcome page.








INFORMATION:

After entering the welcome page 3s, the wired controller will go to the homepage.
No operation for 2 minutes the screen will turn off and click on the screen to turn it back on.
(If there is a communication failure, it will stay on the welcome page.)

3.1.1Single Mode




When the heat pump is running single mode, the following page is displayed.
For example, running heating mode or cooling mode alone.

| Icon |  |  |  |  |
|----------------|---|---|---|---|
| Operation Mode | Underfloor Heating | Hot Water | Heating | Cooling |




3.1.2Muti-Mode

When the heat pump is running muti-mode, the following page is displayed.
For example, when hot water mode and other modes are running at the same time.

| | | | |
|----------------|---|--|---|
| Icon |  |  |  |
| Operation Mode | Underfloor Heating & Hot Water | Heating & Hot Water | Cooling & Hot Water |

Operation Mode Icon

-Current operating mode display of the unit



Mode 1 Operation Status Area

- Current water temperature display
- Target water temperature display

Mode 2 Operation Status Area

- Current water temperature display
- Target water temperature display





INFORMATION:

Other unlabeled areas are displayed the same as single mode.



3.2 Icon Description

Mainly introduces the meaning represented by each display icon on the wired controller.

3.2.1 Unit Status Icon



3.2.2 Water Temperature Icon




INFORMATION:

Under Single mode and Muti-mode, touch the target temperature directly and enter the set temperature in the pop-up input box.


4.Operation

The 5 icons in the operation area allow access to different pages of the wired controller for different functional operations.

4.1ON/OFF Button

Touch "  " to control the unit to turn on and off.

4.2Mode Button

Touch "  " to enter the operation mode selection.




INFORMATION:




After selecting the mode, you can touch "  " to return to the home page quickly.

4.3Function Button

Touch "  " to enter the function setting page, the following will explain each function.



4.3.1 User Function

Touch "  User functions " to enter user function setting page.

Quite Mode

-Reduced compressor frequency and fan speed to reduce unit noise.

Powerful Mode

-Increase the compressor frequency and fan speed to increase the capacity of the unit.

Sterilization Mode

- Unit will operate sterilization mode. Parameters 9-12 are used to set the sterilization mode.

Forced Defrosting

-Unit will operate the defrosting mode.

Fast Heating Mode

-Unit will turn on the AHS and electric heater for fast heating

Waterway Exhaust Mode

- Unit will run the water pump to circulate the water circuit and discharge the air.



NOTE:


When the unit operating silent mode will reduce heating capacity.
When the unit operating powerful mode will increase operating noise.

For Example:


Sterilization Mode:

When 9=1,10=23,11=10,12=70 and the sterilization mode is enabled, the unit will run sterilization once at 23:00 and 7 days interval, the sterilization will continue to run at 70°C water temperature for 10Min and then exit; the next time it will be turned on will be at 23:00 after 7 days.

4.3.2 Timer Function Setting

Touch "  Timing function " to enter timer function setting page.


The wired controller can set the unit to turn on or off on different days and time periods.




-Repeat: Run every day according to the set timer.

-Monday-Sunday: Run the selected date according to the set timer.

4.3.3 Wi-Fi Setting

Touch "  WIFI distribution " to enter Wi-Fi setting page. If you need to use your mobile phone to control the heat pump, you need to turn on Wi-Fi first and then use the app to connect.


For details, refer to Chapter 5




NOTE:

It is recommended to use Intelligent distribution mode.

4.3.4DHW Return Water Function

Touch "  Return water function " to enter the DHW return water setting page.

To maintain the water temperature in the domestic water pipes, the hot water return function can be turned on to keep the water in the water pipes at a constant temperature.






NOTE:

- To enable the DHW return water function, P_e water pump needs to be installed. Please consult the installer for details.
- If the scheduled water return is set, the unit will run the water return function according to the scheduled time; if the scheduled water return is not set, the unit will automatically run the water return function. Parameters 13-14 are the control water return settings.

4.3.5 Factory Function

Touch "  Factory function " to enter the factory function page.




INFORMATION:

Password is 1122.



This page is for factories and installers only.


Adjusting parameters may affect the normal operation of the unit.

4.3.6 Scene Setting

Touch "  Scene settings " to enter the scene setting page.

In the scene setting, you can set the unit to run in different modes and target temperatures on different days and time periods and set different scenes according to different needs.

Mode:  Mode Setting Set Temp: 25 Temp. Setting  ON/OFF Button





| Scene | Time | Mode | Set Temp | ON/OFF Button |
|-------|---------|------|----------|---------------|
| 1 | 06 : 00 | | 25 | |
| 2 | 12 : 00 | | 25 | |
| 3 | 13 : 00 | | 25 | |
| 4 | 18 : 00 | | 25 | |
| 5 | 20 : 00 | | 25 | |
| 6 | 22 : 00 | | 25 | |

Repeat Monday Tuesday Wednesday
Thursday Friday Saturday Sunday

4.3.7Dual Temperature Zone Control

Touch " > " to enter next page and touch " Double temperature zone " to enter the dual temperature zone control setting page. If you need to set different temperatures in two areas of your house at the same time, such as when using radiators and floor heating, you can use a heat pump to control the temperatures of the two areas.






INFORMATION:

Dual Temperature Zone Control is disabled by default.
P257 is used to enable/disable functions. (0-Enable/1-Disable)
Please consult the installer for more settings

4.3.8SG Ready

Touch "  " to enter next page and touch "  Smart power grid " to enter the smart grid setting page. If you are connected to a smart grid, you can set it through this page.




When there is neither SG signal nor EVU signal, you can set the maximum operating time of the unit and then turn off the unit.




INFORMATION:

Smart grid function is disabled by default.
P255 is used to enable/disable functions. (0-Enable/1-Disable)
Please consult the installer for more settings

4.4Query Button

Touch " " to enter the parameter query page. The following will explain each page.



4.4.1User Parameter

All the unit's current user-set parameters can be set on this page, and you can also quickly set the target temperatures for different operating modes on this page.

Touch " User Parameters " to enter the user parameter query page, press "<" ">" to switch pages.

Touch the parameter valve to enter the modify page. Enter the value on the keyboard.



| Number | Parameter | Value | Unit |
|--------|--|-------|------|
| 1 | Heating set temperature | 30 | °C |
| 2 | Cooling set temperature | 22 | °C |
| 3 | Floor heating set temperature | 60 | °C |
| 4 | Hot water set temperature | 55 | °C |
| 5 | Air conditioning return difference value | 5 | °C |



1 Cooling set temperature

Current value : 50 °C


Set value: 50 °C


Set range: 20 ~ 55 °C

OK


4.4.2System Parameter

The system parameters provide detailed feedback on the current operation of the unit, and when the unit is operating abnormally, the system parameters can be provided to the installer for analysis.

Touch " System Parameters " to enter the system parameter query page, press "<" ">" to switch pages.




| < System Parameters | | Back to main page  | |
|---------------------|----------------------------------|---|------|
| Number | Parameter | Value | Unit |
| 1 | Compressor operating frequency | 0 | Hz |
| 2 | Fan running frequency/speed | 0 | Hz |
| 3 | Electronic expansion valve steps | 0 | P |
| 4 | EVI valve steps | 0 | P |
| 5 | AC input voltage | 0 | V |

< 1 >


When unit in cascade mode, touch " System Parameters" and select the units you want to view. Grey means the unit is not connected.


| | | | |
|---------------------|-------|---|--|
| < System Parameters | | Back to main page  | |
| No.01 | No.09 | | |
| No.02 | No.10 | | |
| No.03 | No.11 | | |
| No.04 | No.12 | | |
| No.05 | No.13 | | |
| No.06 | No.14 | | |
| No.07 | No.15 | | |
| No.08 | No.16 | | |

4.4.3 Notification

When the unit shows error information, "" icon will be displayed on the main page, directly touch "" or touch " Notification information" to enter the error message inquiry page.





Touch"  " can clear history of failure.



4.4.4Power Statistics

The built-in power statistics module of the unit can count the power consumption data of the unit.


Touch"  " to query the power statistics.



4.4.5 Operation Curves




The operation curve of the unit can visualize the operation of the unit, including the change of inlet and outlet water temperature, the change of compressor and fan frequency, etc.


Touch "  Temperature Curves " to query the unit running status.



4.4.6 Climate Temperature Curve

Climate temperature curve is used to preset the water outlet temperature depending on the ambient temperature. During the warmer weather the heating is reduced. To save energy, the climate temperature curve can decrease the water outlet temperature when the ambient temperature increased in heating mode.

Touch "  Set Temperature Curves " to enter the climate temperature curve setting page. Touch "  " and "  " to select different temperature curve.



Curve No.

- HH: High temperature curve for heating
- HL: Low temperature curve for heating
- CH: High temperature curve for cooling
- CL: Low temperature curve for cooling
- H: Temperature curve for DHW



INFORMATION:

- Heating mode has 8 built-in curves.
- Cooling mode has 8 built-in curves.
- Hot water mode has 4 built-in curves.



NOTE:

- It only uses the curve of the high temperature setting for heating if the high temperature is set for heating.
- It only uses the curve of the low temperature setting for heating if the low temperature is set for heating.
- It only uses the curve of the high temperature setting for cooling if the high temperature is set for cooling.
- It only uses the curve of the low temperature setting for cooling if the low temperature is set for cooling.
- The water outlet temperature can't be adjusted when the temperature curve is set.
- See the appendix for a table of temperature profiles.

4.5 Setting Button




Touch " " to enter the setting page. For specific setting option, please refer to the following.




NOTE:

Gray options represent features to be improved.

4.5.1 Date & Time


Touch "  Date & Time " to enter the Date & Time setting page. The first installation of the wired controller requires manual setting of the date and time.




Date Format
-DD-MM-YYYY


Time Format
-HH-MM
-24-hour format


4.5.2Dispaly & Sound

Touch"  Display and sound " to enter setting page. You can set the display brightness of the wired controller, turn off the touch sound and change the language display.



4.5.3Factory Parameter

Touch"  Factory Parameters " to enter the factory parameter setting page. Press "<" ">" to switch pages. Touch the parameter valve to enter the modify page. Enter the valve on the keyboard.



When unit in cascade mode, touch"  Factory Parameters " and select the units you want to view. Grey

means the unit is not connected.






INFORMATION:

Password is 0000.


This page is for factories and installers only.

4.5.4Restore Factory Setting

If you want to restore the parameters to their default values or if the unit is running abnormally, you can touch "  " to enter the restore factory setting page. Touch "  " to confirm in the pop-up window.



4.5.5 About

Touch "  About " to check the motherboard and wired controller software version.



5. Smart Life APP


The unit can be controlled remotely from your cell phone, scan the QR code below or search for "Smart Life" in the App Store or Google Play to download the app.



5.1 Register & Login


The first time you enter the APP you need to register, enter your email account and password to register.



After successful registration, enter your account and password to enter the binding page



5.2 Unit Binding

The wired controller needs to be in WIFI distribution mode, refer to section 4.3.3 for details.



- Make sure the wire controller and cell phone are in the same network, the cell phone needs to be connected to WIFI, and then open the Bluetooth and authorize the APP to use, touch " ".
- Wait for the device to be searched, click " ".
- Enter the WI-FI password.
- Bind successfully.




INFORMATION:

Make sure the wire controller and cell phone are in the same network.
Make sure the phone is turn on Bluetooth and authorized APP.


5.3 Using Homepage


5.3.1 ON/OFF

Touch "  " for unit ON/OFF





5.3.2 Mode Setting


Touch "  " to switch unit operation mode.



5.3.3Rename Unit


- Touch "  " to go to the unit information.
- Touch "  "to view the unit's name.
- Touch "Name" to rename the unit.

- Enter the name you want to rename.




5.3.4 Remove Unit

Touch "Remove Device" to unbind the device.




5.3.5 Timer Setting

- Touch "Settings" to enter the unit settings.
- Touch "Timer" to set the timer.
- Select the time you want to set the timer.





5.3.6 Operation Status Query

- Touch "Settings" to enter the unit settings.
- Touch "Query" to check the unit operation parameter.



6. Wired Controller Menu Structure Overview





7.Appendix

7.1Climate Temperature Curves

By selecting the corresponding climate compensation curve, the unit automatically adjusts the water outlet temperature according to the ambient temperature, and the following is the designation of the climate compensation curve on the wired controller:

| High Temperature Curve for Heating | | Low Temperature Curve for Heating | |
|------------------------------------|---------------------|-----------------------------------|---------------------|
| Curves No. | Corresponding Curve | Curves No. | Corresponding Curve |
| HH1 | Heating Curve 1 | HL1 | Heating Curve 1 |
| HH2 | Heating Curve 2 | HL2 | Heating Curve 2 |
| HH3 | Heating Curve 3 | HL3 | Heating Curve 3 |
| HH4 | Heating Curve 4 | HL4 | Heating Curve 4 |
| HH5 | Heating Curve 5 | HL5 | Heating Curve 5 |
| HH6 | Heating Curve 6 | HL6 | Heating Curve 6 |
| HH7 | Heating Curve7 | HL7 | Heating Curve7 |
| HH8 | Heating Curve 8 | HL8 | Heating Curve 8 |

| High Temperature Curve for Cooling | | Low Temperature for Curve Cooling | |
|------------------------------------|---------------------|-----------------------------------|---------------------|
| Curves No. | Corresponding Curve | Curves No. | Corresponding Curve |
| CH1 | Heating Curve 1 | CL1 | Heating Curve 1 |


| High Temperature Curve for Cooling | | Low Temperature for Curve Cooling | |
|------------------------------------|---------------------|-----------------------------------|---------------------|
| Curves No. | Corresponding Curve | Curves No. | Corresponding Curve |
| CH2 | Heating Curve 2 | CL2 | Heating Curve 2 |
| CH3 | Heating Curve 3 | CL3 | Heating Curve 3 |
| CH4 | Heating Curve 4 | CL4 | Heating Curve 4 |
| CH5 | Heating Curve 5 | CL5 | Heating Curve 5 |
| CH6 | Heating Curve 6 | CL6 | Heating Curve 6 |
| CH7 | Heating Curve 7 | CL7 | Heating Curve 7 |
| CH8 | Heating Curve 8 | CL8 | Heating Curve 8 |

7.1.1 Heating Curves

| High Temperature Curve for Heating (HH Curve) | | | | | | | |
|--|-------------------------|---------------------|-------------------------|---------------------|-------------------------|---------------------|-------------------------|
| HH1 | | HH2 | | HH3 | | HH4 | |
| Ambient Temp.(T/°C) | Water Outlet Temp. (°C) | Ambient Temp.(T/°C) | Water Outlet Temp. (°C) | Ambient Temp.(T/°C) | Water Outlet Temp. (°C) | Ambient Temp.(T/°C) | Water Outlet Temp. (°C) |
| ≥16 | 50 | ≥17 | 45 | ≥16 | 45 | ≥19 | 40 |
| 8≤T < 16 | 51 | 14≤T < 17 | 46 | 8≤T < 16 | 46 | 16≤T < 19 | 41 |
| 0≤T < 8 | 52 | 10≤T < 14 | 47 | 0≤T < 8 | 47 | 13≤T < 16 | 42 |
| -8≤T < 0 | 53 | 6≤T < 10 | 48 | -8≤T < 0 | 48 | 10≤T < 13 | 43 |
| -16≤T < -8 | 54 | 2≤T < 6 | 49 | -16≤T < -8 | 49 | 7≤T < 10 | 44 |
| < -16 | 55 | -2≤T < 2 | 50 | < -16 | 50 | 4≤T < 7 | 45 |
| / | / | -6≤T < -2 | 51 | / | / | 1≤T < 4 | 46 |
| / | / | -10≤T < -6 | 52 | / | / | -2≤T < 1 | 47 |
| / | / | -14≤T < -10 | 53 | / | / | -5≤T < -2 | 48 |
| / | / | -20≤T < -14 | 54 | / | / | -8≤T < -5 | 49 |
| / | / | < -20 | 55 | / | / | -10≤T < -8 | 50 |
| / | / | / | / | / | / | -12≤T < -10 | 51 |
| / | / | / | / | / | / | -14≤T < -12 | 52 |
| / | / | / | / | / | / | -16≤T < -14 | 53 |
| / | / | / | / | / | / | -18≤T < -16 | 54 |
| / | / | / | / | / | / | < -18 | 55 |
| | | | | | | | |
| HH5 | | HH6 | | HH7 | | HH8 | |
| Ambient Temp.(T/°C) | Water Outlet Temp. (°C) | Ambient Temp.(T/°C) | Water Outlet Temp. (°C) | Ambient Temp.(T/°C) | Water Outlet Temp. (°C) | Ambient Temp.(T/°C) | Water Outlet Temp. (°C) |

| | | | | | | | |
|--------------------|----|-------------------|----|--------------------|----|-------------------|----|
| ≥ 17 | 40 | ≥ 16 | 40 | ≥ 17 | 35 | ≥ 16 | 35 |
| $14 \leq T < 17$ | 41 | $8 \leq T < 16$ | 41 | $14 \leq T < 17$ | 36 | $8 \leq T < 16$ | 36 |
| $10 \leq T < 14$ | 42 | $0 \leq T < 8$ | 42 | $10 \leq T < 14$ | 37 | $0 \leq T < 8$ | 37 |
| $6 \leq T < 10$ | 43 | $-8 \leq T < 0$ | 43 | $6 \leq T < 10$ | 38 | $-8 \leq T < 0$ | 38 |
| $2 \leq T < 6$ | 44 | $-16 \leq T < -8$ | 44 | $2 \leq T < 6$ | 39 | $-16 \leq T < -8$ | 39 |
| $-2 \leq T < 2$ | 45 | < -16 | 45 | $-2 \leq T < 2$ | 40 | < -16 | 40 |
| $-6 \leq T < -2$ | 46 | / | / | $-6 \leq T < -2$ | 41 | / | / |
| $-10 \leq T < -6$ | 47 | / | / | $-10 \leq T < -6$ | 42 | / | / |
| $-14 \leq T < -10$ | 48 | / | / | $-14 \leq T < -10$ | 43 | / | / |
| $-20 \leq T < -14$ | 49 | / | / | $-20 \leq T < -14$ | 44 | / | / |
| < -20 | 50 | / | / | < -20 | 45 | / | / |


NOTE: Curve 4 and Curve 6 are ECO energy saving curves



| Low Temperature Curve for Heating (HL Curve) | | | | | | | |
|---|-------------------------|---------------------|-------------------------|---------------------|-------------------------|---------------------|-------------------------|
| HL1 | | HL2 | | HL3 | | HL4 | |
| Ambient Temp.(T/°C) | Water Outlet Temp. (°C) | Ambient Temp.(T/°C) | Water Outlet Temp. (°C) | Ambient Temp.(T/°C) | Water Outlet Temp. (°C) | Ambient Temp.(T/°C) | Water Outlet Temp. (°C) |
| ≥ 18 | 32 | ≥ 16 | 30 | ≥ 14 | 30 | ≥ 18 | 28 |
| $9 \leq T < 18$ | 33 | $8 \leq T < 16$ | 31 | $0 \leq T < 14$ | 31 | $13 \leq T < 18$ | 29 |
| $4 \leq T < 9$ | 34 | $0 \leq T < 8$ | 32 | $-14 \leq T < 0$ | 32 | $6 \leq T < 8$ | 30 |
| $-3 \leq T < 4$ | 35 | $-8 \leq T < 0$ | 33 | < -14 | 33 | $0 \leq T < 6$ | 31 |
| $-10 \leq T < -3$ | 36 | $-16 \leq T < -8$ | 34 | / | / | $-5 \leq T < 0$ | 32 |
| $-16 \leq T < -10$ | 37 | < -16 | 35 | / | / | $-9 \leq T < -5$ | 33 |
| < -16 | 38 | / | / | / | / | $-16 \leq T < -9$ | 34 |
| / | / | / | / | / | / | < -16 | 35 |

| HL5 | | HL6 | | HL7 | | HL8 | |
|---------------------|-------------------------|---------------------|-------------------------|---------------------|-------------------------|---------------------|-------------------------|
| Ambient Temp.(T/°C) | Water Outlet Temp. (°C) | Ambient Temp.(T/°C) | Water Outlet Temp. (°C) | Ambient Temp.(T/°C) | Water Outlet Temp. (°C) | Ambient Temp.(T/°C) | Water Outlet Temp. (°C) |
| ≥16 | 28 | ≥16 | 26 | ≥14 | 26 | ≥16 | 24 |
| 8≤T < 16 | 29 | 8≤T < 16 | 27 | 0≤T < 14 | 27 | 8≤T < 16 | 25 |
| 0≤T < 8 | 30 | 0≤T < 8 | 28 | -14≤T < 0 | 28 | 0≤T < 8 | 26 |
| -8≤T < 0 | 31 | -8≤T < 0 | 29 | < -14 | 29 | -8≤T < 0 | 27 |
| -16≤T < -8 | 32 | -16≤T < -8 | 30 | / | / | -16≤T < -8 | 28 |
| < -16 | 33 | < -16 | 31 | / | / | < -16 | 29 |


NOTE: Curve 4 and Curve 6 are ECO energy saving curves



7.1.2Cooling Curves

| High Temperature Curve for Cooling (CH Curve) | | | | | | | |
|--|-------------------------|---------------------|-------------------------|---------------------|-------------------------|---------------------|-------------------------|
| CH1 | | CH2 | | CH3 | | CH4 | |
| Ambient Temp.(T/°C) | Water Outlet Temp. (°C) | Ambient Temp.(T/°C) | Water Outlet Temp. (°C) | Ambient Temp.(T/°C) | Water Outlet Temp. (°C) | Ambient Temp.(T/°C) | Water Outlet Temp. (°C) |
| ≥30 | 16 | ≥30 | 17 | ≥30 | 17 | ≥30 | 18 |
| 22≤T < 30 | 18 | 22≤T < 30 | 18 | 22≤T < 30 | 19 | 22≤T < 30 | 19 |
| 16≤T < 22 | 20 | 16≤T < 22 | 19 | 16≤T < 22 | 21 | 16≤T < 22 | 20 |


| | | | | | | | |
|---|-------------------------|---------------------|-------------------------|---------------------|-------------------------|---------------------|-------------------------|
| < 16 | 22 | < 16 | 20 | < 16 | 23 | < 16 | 21 |
| | | | | | | | |
| CH5 | | CH6 | | CH7 | | CH8 | |
| Ambient Temp.(T/°C) | Water Outlet Temp. (°C) | Ambient Temp.(T/°C) | Water Outlet Temp. (°C) | Ambient Temp.(T/°C) | Water Outlet Temp. (°C) | Ambient Temp.(T/°C) | Water Outlet Temp. (°C) |
| ≥30 | 18 | ≥30 | 19 | ≥30 | 19 | ≥30 | 20 |
| 22≤T < 30 | 20 | 22≤T < 30 | 20 | 22≤T < 30 | 21 | 22≤T < 30 | 21 |
| 16≤T < 22 | 22 | 16≤T < 22 | 21 | 16≤T < 22 | 23 | 16≤T < 22 | 22 |
| < 16 | 24 | < 16 | 22 | < 16 | 25 | < 16 | 23 |
| NOTE: Curve 4 and Curve 6 are ECO energy saving curves | | | | | | | |



| Low Temperature Curve for Cooling (CL Curve) | | | | | | | |
|---|-------------------------|---------------------|-------------------------|---------------------|-------------------------|---------------------|-------------------------|
| CL1 | | CL2 | | CL3 | | CL4 | |
| Ambient Temp.(T/°C) | Water Outlet Temp. (°C) | Ambient Temp.(T/°C) | Water Outlet Temp. (°C) | Ambient Temp.(T/°C) | Water Outlet Temp. (°C) | Ambient Temp.(T/°C) | Water Outlet Temp. (°C) |
| ≥30 | 5 | ≥30 | 6 | ≥30 | 7 | ≥30 | 8 |
| 20≤T < 30 | 8 | 20≤T < 30 | 9 | 20≤T < 30 | 10 | 20≤T < 30 | 11 |
| 16≤T < 22 | 11 | 16≤T < 22 | 12 | 16≤T < 22 | 13 | 16≤T < 22 | 14 |
| < 16 | 17 | < 16 | 18 | < 16 | 18 | < 16 | 19 |
| | | | | | | | |
| CL5 | | CL6 | | CL7 | | CL8 | |
| Ambient Temp.(T/°C) | Water Outlet Temp. (°C) | Ambient Temp.(T/°C) | Water Outlet Temp. (°C) | Ambient Temp.(T/°C) | Water Outlet Temp. (°C) | Ambient Temp.(T/°C) | Water Outlet Temp. (°C) |

| | | | | | | | |
|-----------|----|-----------|----|-----------|----|-----------|----|
| ≥30 | 9 | ≥30 | 10 | ≥30 | 11 | ≥30 | 12 |
| 20≤T < 30 | 12 | 20≤T < 30 | 13 | 20≤T < 30 | 14 | 20≤T < 30 | 15 |
| 16≤T < 22 | 15 | 16≤T < 22 | 16 | 16≤T < 22 | 17 | 16≤T < 22 | 18 |
| < 16 | 20 | < 16 | 21 | < 16 | 22 | < 16 | 23 |


NOTE: Curve 4 and Curve 6 are ECO energy saving curves



7.1.3DHW Curves

| Temperature Curve for DHW (H Curve) | | | | |
|--|-------------------------|----|----|----|
| Ambient Temp.(T/°C) | Water Outlet Temp. (°C) | | | |
| | H1 | H2 | H3 | H4 |
| -25 | 49 | 51 | 53 | 55 |
| -20 | 49 | 51 | 53 | 55 |
| -16 | 49 | 51 | 53 | 55 |
| -15 | 49 | 51 | 53 | 55 |
| -9 | 48 | 50 | 52 | 54 |
| -8 | 48 | 50 | 52 | 54 |
| -1 | 48 | 50 | 52 | 54 |
| 0 | 48 | 50 | 52 | 54 |
| 7 | 47 | 49 | 51 | 53 |

| | | | | |
|----|----|----|----|----|
| 8 | 46 | 48 | 50 | 52 |
| 15 | 45 | 47 | 49 | 51 |
| 16 | 45 | 47 | 49 | 51 |
| 20 | 44 | 46 | 48 | 50 |
| 26 | 43 | 45 | 47 | 49 |
| 31 | 41 | 43 | 45 | 47 |
| 32 | 41 | 43 | 45 | 47 |
| 37 | 40 | 42 | 44 | 46 |
| 38 | 39 | 41 | 43 | 45 |
| 41 | 38 | 40 | 42 | 44 |
| 42 | 38 | 40 | 42 | 44 |
| 45 | 37 | 39 | 41 | 43 |



7.2 Error Code & Troubleshooting

7.2.1 Motherboard

| Error Code | Error Description | Troubleshooting |
|------------|--------------------|--|
| E01 | Wrong Phase | Power Supply Connect Wrong Phase |
| E02 | Missing Phase | Power Supply Missing Phase |
| E03 | Water Flow Failure | 1.Check whether the circulating water pump is normal and whether the water system is |

| Error Code | Error Description | Troubleshooting |
|------------|---|--|
| | | blocked. |
| | | 2.Check whether the water flow switch is normal and whether the installation direction is correct. |
| | | 3.Check whether the wiring of the water flow switch is correct or not. |
| | | 4.Check whether the water pump head meets the actual requirements |
| | | 5.Check whether the water pump is reversed and installed in the wrong direction. |
| E04 | Abnormal Communication between Motherboard and Remote Module (Reserved) | Check the communication connection between the motherboard and the remote module |
| E05 | High Pressure Switch Failure | 1.Check pressure switch for damage, wiring error |
| | | 2.Check if there is too much refrigerant in the system. |
| | | 3.Check whether the fan is working properly and whether the water flow of the unit is normal. |
| | | 4.Check whether there is air or blockage in the fluorine system. |
| | | 5.Check whether the water-side heat exchanger is seriously caked with whitewash. |
| E06 | Low Pressure Switch Failure | 1.Check pressure switch for damage, wiring error |
| | | 2.Check if there is not enough refrigerant in the system. |
| | | 3.Check whether the fan is working properly |
| | | 4.Check whether there is air or blockage in the fluorine system. |
| E09 | Wire Controller Communication Failure | Check the communication connection between the wire controller and the main board |
| E10 | Reserve | Reserve |
| E11 | Out of Use Time | The free trial period has expired, enter the boot password |
| E12 | Exhaust Temp. Too High | 1.Fluorine system clogging |
| | | 2.Lack of refrigerant in the fluorine system or bad sensor |

| Error Code | Error Description | Troubleshooting |
|------------|--|---|
| E14 | Water Tank Temp. Sensor Failure | 1. The sensor wire is loose or damaged |
| | | 2. Sensor is damaged |
| | | 3. The motherboard port is damaged |
| E15 | Water Inlet Temp. Sensor Failure | 1. The sensor wire is loose or damaged |
| | | 2. Sensor is damaged |
| | | 3. The motherboard port is damaged |
| E16 | Coil Temp. Sensor Failure | 1. The sensor wire is loose or damaged |
| | | 2. Sensor is damaged |
| | | 3. The motherboard port is damaged |
| E18 | Exhaust Temp. Sensor Failure | 1. The sensor wire is loose or damaged |
| | | 2. Sensor is damaged |
| | | 3. The motherboard port is damaged |
| E20 | Indoor Ambient Temp. Sensor Failure | 1. The sensor wire is loose or damaged |
| | | 2. Sensor is damaged |
| | | 3. The motherboard port is damaged |
| E21 | Outdoor Ambient Temp. Sensor Failure | 1. The sensor wire is loose or damaged |
| | | 2. Sensor is damaged |
| | | 3. The motherboard port is damaged |
| E22 | DHW Return Water Temp. Sensor Failure | 1. The sensor wire is loose or damaged |
| | | 2. Sensor is damaged |
| | | 3. The motherboard port is damaged |
| E23 | Water Outlet Temp. Too Low in Cooling Mode | 1. Check whether the water flow is too low or no water flow |
| | | 2. Check if the water outlet sensor is damaged |
| | | 3. Fluorine system clogging |
| E24 | Antifreeze Temp. Sensor Failure (Fluorine Circuit) | 1. The sensor wire is loose or damaged |
| | | 2. Sensor is damaged |
| | | 3. The motherboard port is damaged |
| E25 | Reserve | Reserve |
| E26 | Antifreeze Temp. Sensor Failure (Water Circuit) | 1. The sensor wire is loose or damaged |
| | | 2. Sensor is damaged |
| | | 3. The motherboard port is damaged |
| E27 | Water Outlet Temp. Sensor Failure | 1. The sensor wire is loose or damaged |
| | | 2. Sensor is damaged |

| Error Code | Error Description | Troubleshooting |
|------------|---|---|
| | | 3. The motherboard port is damaged |
| E29 | Suction Temp. Sensor Failure | 1. The sensor wire is loose or damaged |
| | | 2. Sensor is damaged |
| | | 3. The motherboard port is damaged |
| E30 | Suction Temp. Sensor Failure | 1. The sensor wire is loose or damaged |
| | | 2. Sensor is damaged |
| | | 3. The motherboard port is damaged |
| E31 | Water Pressure Failure | 1. Water pressure switch wiring error |
| | | 2. Water pressure switch failure |
| E32 | Water Outlet Temp. Sensor T15 Failure | 1. Water flow is not enough |
| | | 2. Sensor failure |
| E33 | High Pressure Sensor Failure | 1. The sensor wire is loose or damaged |
| | | 2. Sensor is damaged |
| | | 3. The motherboard port is damaged |
| E34 | Low Pressure Sensor Failure | 1. The sensor wire is loose or damaged |
| | | 2. Sensor is damaged |
| | | 3. The motherboard port is damaged |
| E37 | Large Temp. Difference between Water Inlet and Outlet | 1. The water inlet or outlet sensor is damaged |
| | | 2. Water inlet or outlet sensor not placed or in the wrong position |
| | | 3. Water flow is not enough |
| E38 | Fan Failure | Fan driver board or motor failure |
| E42 | Cooling Coil Temp. Sensor Failure | 1. The sensor wire is loose or damaged |
| | | 2. Sensor is damaged |
| | | 3. The motherboard port is damaged |
| E44 | Ambient Temp. Too Low | Normal protection |
| E47 | Economizer Inlet Temp. Sensor Failure | 1. The sensor wire is loose or damaged |
| | | 2. Sensor is damaged |
| | | 3. The motherboard port is damaged |
| E48 | Economizer Inlet Temp. Sensor Failure | 1. The sensor wire is loose or damaged |
| | | 2. Sensor is damaged |
| | | 3. The motherboard port is damaged |
| E49 | Economizer Outlet Temp. Sensor Failure | Same as E47 |

| Error Code | Error Description | Troubleshooting |
|------------|--|---|
| E51 | High Pressure Too High | Same as E05 |
| E52 | Low Pressure Too Low | Same as E06 |
| E55 | Expansion Board Communication Failure | 1.Poor contact or broken signal wire |
| | | 2.Expansion board damage |
| | | 3.Motherboard damage |
| E80 | Power Supply Error | Single-phase power supply unit detects a three-phase electrical signal |
| E88 | Inverter Drive Module Protection | Compressor or compressor driver board is damaged, specific faults see 7.2.2 |
| E94 | Built-in pump over/under voltage | 1. Input power supply voltage < 165V |
| | | 2. Input power supply voltage > 265V |
| | | 3. Electronic components on the pump drive board are damaged or damp |
| | | 4. Water pump failure |
| E96 | Compressor Drive Board Communication Failure | 1.Poor contact or broken signal wire |
| | | 2.Electronic components on the motherboard are damaged or damp. |
| | | 3.Compressor drive board on the electronic components are damaged or moisture |
| | | 4.Compressor drive board power supply is not powered on |
| E98 | Fan Board Communication Failure | 1.Poor contact or broken signal wire |
| | | 2.Electronic components on the motherboard are damaged or damp. |
| | | 3.Fan drive board on the electronic components are damaged or moisture |
| | | 4.Fan drive board power supply is not powered on |
| EA1 | Cascade Model Mismatch | Different series of units are not allowed to be cascaded |
| EA2 | Solar Water Heater Temp. Sensor Failure | 1. The sensor wire is loose or damaged |
| | | 2. Sensor is damaged |
| | | 3. The motherboard port is damaged |
| EA3 | Zone 2 Temp. Sensor Failure | 1. The sensor wire is loose or damaged |
| | | 2. Sensor is damaged |
| | | 3. The motherboard port is damaged |

| Error Code | Error Description | Troubleshooting |
|------------|---|--|
| EA4 | Buffer Tank Temp. Sensor Failure | 1. The sensor wire is loose or damaged |
| | | 2. Sensor is damaged |
| | | 3. The motherboard port is damaged |
| EA5 | Total Water Outlet Temp. Sensor Failure | 1. The sensor wire is loose or damaged |
| | | 2. Sensor is damaged |
| | | 3. The motherboard port is damaged |

7.2.2 Driver Board (Compressor)

| Compressor Drive Error Description Table | | |
|--|-----|---|
| E88 | P1 | IPM Module Overheat and Shutdown |
| | P2 | Compressor Driver Failure |
| | P3 | Compressor Overcurrent |
| | P4 | Input Voltage Missing Phase |
| | P5 | IPM Supply Voltage Failure |
| | P6 | Power Component Overheating and Shutdown |
| | P7 | Pre-charge Circuit Voltage Failure |
| | P8 | DC Bus Overvoltage |
| | P9 | DC Bus Undervoltage |
| | P10 | AC Input Undervoltage |
| | P11 | AC Input Overvoltage |
| | P12 | Input Voltage Sampling Failure |
| | P13 | DSP and PFC Communication Failure |
| | P14 | Board Radiator Temp. Sensor Failure |
| | P15 | DSP and Communicate Board Communication Failure |
| | P16 | Communication Failure with Motherboard |
| | P17 | Compressor Overcurrent Alarm |
| | P18 | Compressor Weak Magnetic Protection Alarm |
| | P19 | IPM Overheat Alarm |
| | P20 | PFC Overheat Alarm |
| | P21 | AC Input Overcurrent Alarm |
| | P22 | EEPROM Error Alarm |

| Compressor Drive Error Description Table | | |
|---|-----|---|
| | P23 | N/A |
| | P24 | EEPROM Refresh Complete |
| | P25 | Temperature Sensing Failure Limit |
| | P26 | AC Undervoltage Frequency Limit Protection Alarm; |
| | P27 | N/A |
| | P28 | N/A |
| | P29 | N/A |
| | P30 | N/A |
| | P31 | N/A |
| | P32 | N/A |
| | P33 | IPM Module Overheat and Shutdown |
| | P34 | Compressor Missing Phase |
| | P35 | Compressor Overload |
| | P36 | Input Current Sampling Failure |
| | P37 | IPM Supply Voltage Failure |
| | P38 | Pre-charge Circuit Voltage Failure |
| | P39 | EEPROM Failure |
| | P40 | AC Input Overvoltage Failure |
| | P41 | Microelectronics Failure |
| | P42 | Compressor Type Code Failure |
| | P43 | Current Sampling Signal Overcurrent |
| Wire controller blinks to cycle through E88 and above codes | | |

7.3Parameter

7.3.1Operation Parameter

| No. | Description | Setting Range | No. | Description | Setting Range |
|-----|------------------------------|---------------|-----|---------------------------------------|---------------|
| 1 | Compressor Running Frequency | 0~150Hz | 31 | System 2 Compressor Running Frequency | |
| 2 | Fan Running Speed | 0~999Hz | 32 | System 2 Fan Running Speed | |
| 3 | EEV Open Step | 0~480P | 33 | System 2 EEV Open Step | |
| 4 | EVI Valve Open Step | 0~480P | 34 | System 2 EVI Valve Open Step | |
| 5 | AC Input Voltage | 0~500V | 35 | System 2 AC Input Voltage | |

| No. | Description | Setting Range | No. | Description | Setting Range |
|-----|------------------------------------|---------------|-----|---|---------------|
| 6 | AC Input Current | 0~50.0A | 36 | System 2 AC Input Current | |
| 7 | Compressor Phase Current | 0~50.0A | 37 | System 2 Compressor Phase Current | |
| 8 | Compressor IPM Temp. | -40~140℃ | 38 | System 2 Compressor IPM Temp. | |
| 9 | High Pressure Saturation Temp. | -50~200℃ | 39 | System 2 High Pressure Saturation Temp. | |
| 10 | Low Pressure Saturation Temp. | -50~200℃ | 40 | System 2 Low Pressure Saturation Temp. | |
| 11 | Ambient Temp. T1 | -40~140℃ | 41 | System 2 Outer Coil Temp. | |
| 12 | Outer Coil Temp. T2 | -40~140℃ | 42 | System 2 Inner Coil Temp. | |
| 13 | Inner Coil Temp. T3 | -40~140℃ | 43 | System 2 Suction Temp. | |
| 14 | Suction Temp. T4 | -40~140℃ | 44 | System 2 Exhaust Temp. | |
| 15 | Exhaust Temp. T5 | 0~150℃ | 45 | System 2 Economizer Inlet Temp. | |
| 16 | Water Inlet Temp. T6 | -40~140℃ | 46 | System 2 Economizer Outlet Temp. | |
| 17 | Water Outlet Temp. T7 | -40~140℃ | 47 | Reserve | |
| 18 | Economizer Inlet Temp. T8 | -40~140℃ | 48 | Reserve | |
| 19 | Economizer Outlet Temp. T9 | -40~140℃ | 49 | Reserve | |
| 20 | Current Unit Tool Number | 0~120 | 50 | Reserve | |
| 21 | DHW Tank Temp. | -40~140℃ | 51 | Solar Water Heater Temp. | |
| 22 | Plate Heat Exchanger Exhaust Temp. | -40~140℃ | 52 | Zone 2 Temp. | |
| 23 | Driver Manufacturer | 0~10 | 53 | Butter Tank Temp. | |
| 24 | Water Pump Speed PWM | 0~100% | 54 | Total Water Outlet Temp. | |
| 25 | Water Flow | 3~100L/min | 55 | Unit B Phase Input Voltage | |
| 26 | DHW Return Water Temp. | -40~140℃ | 56 | Unit B Phase Input Current | |
| 27 | Unit Input Voltage | 0-500V | 57 | Unit C Phase Input Voltage | |
| 28 | Unit Input Current | 0.00A-99.99A | 58 | Unit C Phase Input Current | |
| 29 | Unit Input Power | 0.00-99.99KW | 59 | Smart Grid Status | |
| 30 | Unit Power Consumption | 0-9999Kw.h | 60 | Zone 2 Mixing Valve Opening | |

7.3.2Factory Parameter

| No. | Description | Default Value | Setting Range | Note |
|-----|-----------------------------|---------------|---------------|------|
| L12 | Sterilization | 0 | 0~2 | |
| L13 | Days between Sterilizations | 7 | 5~30 | |
| L14 | Sterilization Start-up Time | 23:00 | 00:00-24:00 | |
| L15 | Sterilization Running Time | 10 | 0-50Min | |
| L16 | Sterilization Temp Setting | 70℃ | 50-80℃ | |

| No. | Description | Default Value | Setting Range | Note |
|-----|---------------------------------------|---------------|---------------|--|
| L22 | DHW return water Setting | 0 | 0~3 | 0-Disable / 1-Continuous return / 2-Cycle return / 3-Temperature |
| L23 | Return Water Temp Setting | 40℃ | 20~65℃ | |
| L24 | Return Water Return Temp Differential | 5℃ | 1~15℃ | |
| L25 | Return Water Interval Period | 30min | 3~90min | |
| L26 | Return Water Running Period | 5min | 1~30min | |

